Service Manual



515-40

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section D - Controls

Section E - Hydraulics

Section F - Transmissions

Section G - Brakes

Section H - Steering

Section K - Engine



Publication No. **9803/9900-4**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class

Section 1



General Information

Service Manual - 515-40

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section D - Controls

Section E - Hydraulics

Section F - Transmissions

Section G - Brakes

Section H - Steering

Section K - Engine



Publication No. **9803/9900-4**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class



Section 1 - General Information

Notes:			

1-0 9803/9900-4 **1-0**



Section 1 - General Information

Contents	Page No
Introduction	
About This Publication	1-1
Identifying Your Machine	1-3
Moving a Disabled Machine	1-8
Transporting the Machine	
Lifting the Machine	
Standard Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	
Hydraulic Connections	1-17
Service Tools	
Numerical List	1-21
Tool Detail Reference	1-23
Service Consumables	
Sealing and Retaining Compounds	1-39
Terms and Definitions	
Colour Coding	1-41

1-i 1-i



Section 1 - General Information

Contents Page No.

1-ii 1-ii

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$