#### **Service Manual**



### **Skid Steer Small Platform**

Service Manual - Skid Steer Small Platform

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section J - Tracks

Section K - Engine



Publication No. **9813/1350-2** 



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class Customer Suppor

#### **Section 1**



#### **General Information**

Service Manual - Skid Steer Small Platform

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section J - Tracks

Section K - Engine



Publication No. **9813/1350** 



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class Customer Support



#### **Section 1 - General Information**

Notes:		
Titolog.		

**1-0** 9813/1350 **1-0** 



## **Section 1 - General Information**

Contents	Page No.
Introduction	
About this Publication	1-1
Machine Model and Serial Number	1-1
Using the Service Manual	
Section Numbering	
Left Side, Right Side	
Cab/Canopy	
Machine Description	
The JCB Skid Steer Loader	
Intended Use	
Component Locations	
Identifying Your Machine	
Machine Identification Plate	
Component Identification	
ROPS and FOPS	
Torque Settings Zinc Plated Fasteners and Dacromet Fasteners Introduction	1-9
Bolts and Screws	
Hydraulic Connections	
'O' Ring Face Seal System	1-13
Service Tools	
Numerical List	1-15
Tool Detail Reference	1-17
Section B - Frame and Bodywork	1-17
Section C - Electrics	1-21
Section E - Hydraulics	1-22
Section K - Engine	1-26
Service Aids	
Sealing and Retaining Compounds	1_27



Contents Page No.

1-ii 1-ii

It's a preview. You can download the full file by clicking the link below.

# https://shopservicemanual.com/

Service Manuals from 2\$