

Shop Manual

BULLDOZER

D155AX-8

SERIAL NUMBERS 100001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-22
FOREWORD, SAFETY, BASIC INFORMATION	00-28
HOW TO READ THE SHOP MANUAL	00-28
SAFETY NOTICE FOR OPERATION	00-30
PRECAUTIONS TO PREVENT FIRE	00-38
ACTIONS IF FIRE OCCURS	00-40
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-41
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS	00-42
PRECAUTIONS FOR DEF	00-43
STORE AdBlue/DEF	00-44
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-45
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS	00-48
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT	00-55
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-57
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-58
PRACTICAL USE OF KOMTRAX	00-59
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-60
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-64
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-68
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-69
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-71
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-72
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-74
HOW TO READ ELECTRICAL WIRE CODE	00-75
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD	00-79
STANDARD TIGHTENING TORQUE TABLE	00-82
CONVERSION TABLE	00-89
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-12
WEIGHT TABLE	01-24
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-29
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-5
UREA SCR SYSTEM	10-11
LAYOUT DRAWING OF UREA SCR SYSTEM	10-11
UREA SCR SYSTEM DIAGRAM	10-13
FUNCTION OF UREA SCR SYSTEM	10-14
COMPONENT PARTS OF UREA SCR SYSTEM	10-31
BOOT-UP SYSTEM	10-40
SYSTEM OPERATING LAMP SYSTEM	10-40
BATTERY DISCONNECT SWITCH	10-42
ENGINE SYSTEM	10-44
LAYOUT DRAWING OF ENGINE SYSTEM	10-44
ENGINE CONTROL SYSTEM	10-46
AUTOMATIC IDLE STOP SYSTEM	10-49
COMPONENT PARTS OF ENGINE SYSTEM	10-52
COOLING SYSTEM	10-72
LAYOUT DRAWING OF COOLING SYSTEM	10-72
COMPONENT PARTS OF COOLING SYSTEM	10-74

CONTROL SYSTEM.....	10-90
LAYOUT DRAWING OF CONTROL SYSTEM	10-90
MACHINE MONITOR SYSTEM	10-91
KOMTRAX SYSTEM.....	10-94
COMPONENT PARTS OF CONTROL SYSTEM.....	10-95
HYDRAULIC SYSTEM.....	10-128
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-128
CLSS	10-129
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-132
POWER TRAIN SYSTEM	10-195
LAYOUT OF POWER TRAIN SYSTEM	10-195
OPERATION OF POWER TRAIN SYSTEM.....	10-198
LAYOUT OF POWER TRAIN SYSTEM (D155PX-8).....	10-200
OPERATION OF POWER TRAIN SYSTEM (D155PX-8)	10-203
TRANSMISSION, STEERING, AND BRAKE CONTROL	10-204
PALM COMMAND CONTROL SYSTEM.....	10-207
HSS SYSTEM.....	10-211
CENTRALIZED PRESSURE PICKUP PORT.....	10-214
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-216
WORK EQUIPMENT SYSTEM	10-299
WORK EQUIPMENT CONTROL	10-299
LAYOUT DRAWING OF FRONT WORK EQUIPMENT	10-301
LAYOUT OF VARIABLE GIANT RIPPER.....	10-302
LAYOUT OF VARIABLE MULTI-SHANK RIPPER	10-303
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-304
UNDERCARRIAGE AND FRAME.....	10-321
MAIN FRAME	10-321
SUSPENSION	10-322
TRACK FRAME AND IDLER CUSHION	10-325
WORK EQUIPMENT.....	10-327
STRUCTURE OF FRONT WORK EQUIPMENT.....	10-327
STRUCTURE OF CYLINDER STAY	10-329
STRUCTURE OF VARIABLE GIANT RIPPER.....	10-330
STRUCTURE OF VARIABLE MULTI-SHANK RIPPER	10-331
CAB AND ITS ATTACHMENTS	10-332
ROPS CAB	10-332
CAB MOUNT	10-333
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: D155AX-8	20-9
STANDARD VALUE TABLE FOR ENGINE: D155PX-8	20-14
STANDARD VALUE TABLE FOR MACHINE.....	20-19
STANDARD VALUE TABLE FOR MACHINE: D155AX-8	20-19
STANDARD VALUE TABLE FOR MACHINE: D155PX-8	20-37
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-53
STANDARD VALUE TABLE FOR ELECTRICAL	20-55
STANDARD VALUE TABLE FOR ELECTRICITY	20-55
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-5
RELATED INFORMATION ON TESTING AND ADJUSTING	30-11
TOOLS FOR TESTING AND ADJUSTING.....	30-11
SKETCH OF TOOLS FOR TESTING AND ADJUSTING	30-19
ENGINE AND COOLING SYSTEM.....	30-22
TEST ENGINE SPEED	30-22
TEST BOOST PRESSURE.....	30-27

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$