

Shop Manual

BULLDOZER

D155AXi-8

SERIAL NUMBERS 100040 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-23
FOREWORD, SAFETY, BASIC INFORMATION	00-29
HOW TO READ THE SHOP MANUAL.....	00-29
SAFETY NOTICE FOR OPERATION.....	00-31
PRECAUTIONS TO PREVENT FIRE.....	00-39
ACTIONS IF FIRE OCCURS	00-41
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-42
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-43
PRECAUTIONS FOR DEF.....	00-44
STORE AdBlue/DEF	00-45
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-46
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-49
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-56
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-58
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-59
PRACTICAL USE OF KOMTRAX	00-60
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-61
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-65
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-69
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-72
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-73
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-75
HOW TO READ ELECTRICAL WIRE CODE	00-76
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-80
STANDARD TIGHTENING TORQUE TABLE.....	00-83
CONVERSION TABLE	00-90
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-11
WEIGHT TABLE	01-18
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-20
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-5
UREA SCR SYSTEM.....	10-11
LAYOUT DRAWING OF UREA SCR SYSTEM	10-11
UREA SCR SYSTEM DIAGRAM	10-13
FUNCTION OF UREA SCR SYSTEM.....	10-14
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-30
BOOT-UP SYSTEM	10-39
SYSTEM OPERATING LAMP SYSTEM	10-39
BATTERY DISCONNECT SWITCH	10-41
ENGINE SYSTEM	10-43
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-43
ENGINE CONTROL SYSTEM	10-45
AUTOMATIC IDLE STOP SYSTEM	10-48
COMPONENT PARTS OF ENGINE SYSTEM	10-51
COOLING SYSTEM.....	10-71
LAYOUT DRAWING OF COOLING SYSTEM	10-71
COMPONENT PARTS OF COOLING SYSTEM.....	10-73

CONTROL SYSTEM.....	10-89
LAYOUT DRAWING OF CONTROL SYSTEM	10-89
MACHINE MONITOR SYSTEM	10-90
KOMTRAX SYSTEM.....	10-93
COMPONENT PARTS OF CONTROL SYSTEM.....	10-94
HYDRAULIC SYSTEM.....	10-127
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-127
CLSS	10-128
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-131
POWER TRAIN SYSTEM	10-194
LAYOUT OF POWER TRAIN SYSTEM	10-194
OPERATION OF POWER TRAIN SYSTEM.....	10-197
TRANSMISSION, STEERING, AND BRAKE CONTROL	10-199
PALM COMMAND CONTROL SYSTEM.....	10-202
HSS SYSTEM.....	10-206
CENTRALIZED PRESSURE PICKUP PORT.....	10-209
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-211
WORK EQUIPMENT SYSTEM	10-291
WORK EQUIPMENT CONTROL	10-291
LAYOUT DRAWING OF FRONT WORK EQUIPMENT	10-293
LAYOUT OF VARIABLE GIANT RIPPER.....	10-294
LAYOUT OF VARIABLE MULTI-SHANK RIPPER	10-295
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-296
ICT SYSTEM	10-313
LAYOUT DRAWING OF ICT SYSTEM.....	10-313
ICT CONTROL SYSTEM DIAGRAM.....	10-315
BLADE CONTROL SYSTEM	10-317
SMOOTH START SYSTEM	10-322
SLIP CONTROL SYSTEM	10-324
ASSIST CONTROL SYSTEM	10-325
COMPONENT PARTS OF ICT SYSTEM	10-327
UNDERCARRIAGE AND FRAME.....	10-339
MAIN FRAME	10-339
SUSPENSION	10-340
TRACK FRAME AND IDLER CUSHION	10-343
WORK EQUIPMENT.....	10-345
STRUCTURE OF FRONT WORK EQUIPMENT.....	10-345
STRUCTURE OF CYLINDER STAY	10-347
STRUCTURE OF VARIABLE GIANT RIPPER.....	10-348
STRUCTURE OF VARIABLE MULTI-SHANK RIPPER	10-349
CAB AND ITS ATTACHMENTS	10-350
ROPS CAB	10-350
CAB MOUNT	10-351
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: D155AXI-8	20-9
STANDARD VALUE TABLE FOR MACHINE.....	20-14
STANDARD VALUE TABLE FOR MACHINE: D155AXI-8	20-14
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-35
STANDARD VALUE TABLE FOR ELECTRICAL	20-37
STANDARD VALUE TABLE FOR ELECTRICITY	20-37
30 TESTING AND ADJUSTING.....	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-6
RELATED INFORMATION ON TESTING AND ADJUSTING	30-12
TOOLS FOR TESTING AND ADJUSTING.....	30-12

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$