

Shop Manual

BULLDOZER

D61EXi -24E0
D61PXi -24E0

SERIAL NUMBERS D61EXi-41275 and up
 D61PXi-41275

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-21
FOREWORD, SAFETY, BASIC INFORMATION	00-27
HOW TO READ THE SHOP MANUAL.....	00-27
SAFETY NOTICE FOR OPERATION.....	00-29
PRECAUTIONS TO PREVENT FIRE.....	00-37
ACTIONS IF FIRE OCCURS	00-39
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-40
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-41
PRECAUTIONS FOR DEF.....	00-42
STORE AdBlue/DEF	00-43
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-44
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-47
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-54
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-56
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-57
PRACTICAL USE OF KOMTRAX	00-58
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-59
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-63
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-67
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-68
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-71
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-73
HOW TO READ ELECTRICAL WIRE CODE	00-74
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-78
STANDARD TIGHTENING TORQUE TABLE.....	00-81
CONVERSION TABLE	00-88
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-12
WEIGHT TABLE	01-23
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-27
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
UREA SCR SYSTEM.....	10-12
LAYOUT DRAWING OF UREA SCR SYSTEM	10-12
UREA SCR SYSTEM DIAGRAM	10-15
FUNCTION OF UREA SCR SYSTEM.....	10-16
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-32
BOOT-UP SYSTEM	10-41
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-41
SYSTEM OPERATING LAMP SYSTEM	10-42
BATTERY DISCONNECT SWITCH	10-44
ENGINE SYSTEM	10-46
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-46
ENGINE CONTROL SYSTEM	10-48
AUTOMATIC IDLE STOP SYSTEM	10-54
COMPONENT PARTS OF ENGINE SYSTEM	10-57
COOLING SYSTEM.....	10-76
LAYOUT DRAWING OF COOLING SYSTEM	10-76

COOLING FAN CONTROL SYSTEM.....	10-78
COMPONENT PARTS OF COOLING SYSTEM.....	10-81
CONTROL SYSTEM.....	10-91
LAYOUT DRAWING OF CONTROL SYSTEM	10-91
MACHINE MONITOR SYSTEM	10-92
KOMTRAX SYSTEM.....	10-93
COMPONENT PARTS OF CONTROL SYSTEM.....	10-94
HYDRAULIC SYSTEM.....	10-128
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-128
CLSS	10-129
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-132
POWER TRAIN SYSTEM	10-167
LAYOUT DRAWING OF HST SYSTEM	10-167
OPERATION OF HST SYSTEM.....	10-168
STEERING AND BRAKE CONTROL SYSTEM	10-170
HST CONTROL SYSTEM.....	10-172
PARKING BRAKE CONTROL SYSTEM	10-183
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-186
WORK EQUIPMENT SYSTEM	10-222
WORK EQUIPMENT CONTROL	10-222
LAYOUT DRAWING OF FRONT WORK EQUIPMENT	10-225
LAYOUT OF FIXED MULTI-SHANK RIPPER.....	10-226
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-227
ICT SYSTEM	10-246
LAYOUT DRAWING OF ICT SYSTEM.....	10-246
ICT CONTROL SYSTEM DIAGRAM.....	10-248
BLADE CONTROL SYSTEM	10-250
SMOOTH START SYSTEM	10-256
SLIP CONTROL SYSTEM	10-258
ASSIST CONTROL SYSTEM	10-259
HST SPEED RANGE CONTROL SYSTEM	10-261
COMPONENT PARTS OF ICT SYSTEM	10-263
UNDERCARRIAGE AND FRAME.....	10-286
MAIN FRAME	10-286
SUSPENSION	10-287
TRACK FRAME AND IDLER CUSHION	10-290
WORK EQUIPMENT.....	10-293
STRUCTURE OF FRONT WORK EQUIPMENT.....	10-293
STRUCTURE OF FIXED MULTI-SHANK RIPPER.....	10-294
CAB AND ITS ATTACHMENTS	10-295
ROPS CAB	10-295
CAB MOUNT	10-297
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: D61EXI-24E0.....	20-9
STANDARD VALUE TABLE FOR ENGINE: D61PXI-24E0.....	20-13
STANDARD VALUE TABLE FOR MACHINE.....	20-17
STANDARD VALUE TABLE FOR MACHINE: D61EXI-24E0	20-17
STANDARD VALUE TABLE FOR MACHINE: D61PXI-24E0	20-34
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-51
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-6
RELATED INFORMATION ON TESTING AND ADJUSTING	30-12
TOOLS FOR TESTING AND ADJUSTING.....	30-12
SKETCH OF TOOLS FOR TESTING AND ADJUSTING	30-19

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$