

# Shop Manual

HYDRAULIC  
EXCAVATOR

**GALEO**

**PC160LC-7E0**

SERIAL NUMBERS 20001 and up

**ecot3**

**KOMATSU**

---

# HYDRAULIC EXCAVATOR

## PC160LC-7E0

**Machine model      Serial number**

PC160LC-7E0          20001 and up

---

## 00 Index and foreword

### Index

---

Composition of shop manual .....	2
Table of contents .....	4

## Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN01892-03
00 Index and foreword	SEN01893-03
Index	SEN01894-03 ●
Foreword and general information	SEN01895-02 ●
01 Specification	SEN01896-00
Specification and technical data	SEN01897-00
10 Structure, function and maintenance standard	SEN01898-01
Engine and cooling system	SEN01899-00
Power train system	SEN01900-00
Undercarriage and frame	SEN01901-01 ●
Hydraulic system, Part 1	SEN01902-00
Hydraulic system, Part 2	SEN01903-00
Hydraulic system, Part 3	SEN01967-00
Work equipment	SEN01904-00
Cab and its attachments	SEN01905-00
Electrical system	SEN01906-00
20 Standard value table	SEN01907-00
Standard service value table	SEN02107-00
30 Testing and adjusting	SEN01908-01
Testing and adjusting, Part 1	SEN02108-01 ●
Testing and adjusting, Part 2	SEN02109-01 ●
Testing and adjusting, Part 3	SEN02110-01 ●
40 Troubleshooting	SEN01909-01
Failure code table and fuse locations	SEN02111-00
General information on troubleshooting	SEN02112-01 ●
Troubleshooting by failure code, Part 1	SEN02113-00
Troubleshooting by failure code, Part 2	SEN02114-00
Troubleshooting by failure code, Part 3	SEN02115-00
Troubleshooting by failure code, Part 4	SEN02116-00
Troubleshooting of electrical system (E-mode)	SEN02117-00

---

Troubleshooting of hydraulic and mechanical system (H-mode)	SEN02118-00
Troubleshooting of engine (S-mode)	SEN02119-01 ●
50 Disassembly and assembly	SEN01910-01
General information on disassembly and assembly	SEN02447-01 ●
Engine and cooling system	SEN02448-01 ●
Power train	SEN02449-00
Undercarriage and frame	SEN02450-00
Hydraulic system	SEN02451-00
Work equipment Body	SEN02452-01 ●
Cab and its attachments	SEN02453-01 ●
Electrical system	SEN02454-01 ●
90 Diagrams and drawings	SEN01911-01
Hydraulic diagrams and drawings	SEN01912-00
Electrical diagrams and drawings	SEN01913-01 ●

## Table of contents

00 Index and foreword	
Index	SEN01894-03
Composition of shop manual .....	2
Table of contents .....	4
Foreword and general information	SEN01895-02
Safety notice .....	2
How to read the shop manual .....	7
Explanation of terms for maintenance standard .....	9
Handling of electric equipment and hydraulic component .....	11
Handling of connectors newly used for engines .....	20
How to read electric wire code .....	23
Precautions when carrying out operation .....	26
Method of disassembling and connecting push-pull type coupler .....	29
Standard tightening torque table .....	32
Conversion table .....	36
01 Specification	
Specification and technical data	SEN01897-00
Specification dimension drawings .....	2
Specifications .....	4
Weight table .....	6
Table of fuel, coolant and lubricants .....	8
10 Structure, function and maintenance standard	
Engine and cooling system	SEN01899-00
Engine related parts .....	2
Radiator, oil cooler, aftercooler and fuel cooler .....	3
Power train system	SEN01900-00
Power train .....	2
Swing circle .....	3
Swing machinery .....	4
Final drive .....	6
Sprocket .....	8
Undercarriage and frame	SEN01901-01
Track frame, recoil spring .....	2
Idler .....	4
Carrier roller .....	6
Track roller .....	7
Track shoe .....	8
Hydraulic system, Part 1	SEN01902-00
Hydraulic equipment layout drawing .....	2
Hydraulic tank .....	4
Hydraulic pump .....	6
Hydraulic system, Part 2	SEN01903-00
Control valve .....	2
CLSS .....	16
Functions and operation by valve .....	20
Hydraulic system, Part 3	SEN01967-00
Valve control .....	2
PPC valve .....	3
Solenoid valve .....	20
Accumulator .....	22

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$