Manual No. : KM-1M9-E Vol. No. : W1M9-E-00

# Workshop Manual



Service Manual (Manual No. KM-1M9-E) consists of the following two separate volumes;

Technical Manual : Vol. No. T1M9-E Workshop Manual : Vol. No. W1M9-E

## INTRODUCTION

## TO THE READER

- This manual is written for an experienced technician to provide technical information needed to maintain and repair this machine.
  - Be sure to thoroughly read this manual for correct product information and service procedures.
- If you have any questions or comments, at if you found any errors regarding the contents of this manual, please contact using "Service Manual Revision Request Form" at the end of this manual.

(Note: Do not tear off the form. Copy it for usage.):

Publications Marketing & Product Support Hitachi Construction Machinery Co. Ltd.

TEL: 81-298-32-7173 FAX: 81-298-31-1162

## **ADDITIONAL REFERENCES**

- Please refer to the materials listed below in addition to this manual.
  - · The Operator's Manual
  - · The Parts Catalog

- · Operation Manual of the Engine
- · Parts Catalog of the Engine
- · Hitachi Training Material

## MANUAL COMPOSITION

- This manual consists of two portions: the Technical Manual and the Workshop Manual. Use the manuals according to purpose.
  - Information included in the Technical Manual: technical information needed for redelivery and delivery, operation and activation of all devices and systems, operational performance tests, and troubleshooting procedures.
- Information included in the Workshop Manual: technical information needed for maintenance and repair of the machine, tools and devices needed for maintenance and repair, maintenance standards, and removal/installation and assemble/disassemble procedures.

## **PAGE NUMBER**

 Each page has a number, located on the center lower part of the page, and each number contains the following information:

Example : T 1-3-5

Consecutive Page Number for Each Group

Group Number

Section Number

T: Technical Manual W: Workshop Manual

## INTRODUCTION

## SAFETY ALERT SYMBOL AND HEADLINE NOTATIONS

In this manual, the following safety alert symbol and signal words are used to alert the reader to the potential for personal injury of machine damage.

This is the safety alert symbol. When you see this symbol, be alert to the potential for personal injury. Never fail to follow the safety instructions prescribed along with the safety alert symbol.

The safety alert symbol is also used to draw attention to component/part weights.

To avoid injury and damage, be sure to use appropriate lifting techniques and equipment when lifting heavy parts.

## • A CAUTION:

Indicated potentially hazardous situation which could, if not avoided, result in personal injury or death.

## • IMPORTANT:

Indicates a situation which, if not conformed to the instructions, could result in damage to the machine.

• ØNOTE:

Indicates supplementary technical information or know-how.

## **UNITS USED**

• SI Units (International System of Units) are used in this manual.

MKSA system units and English units are also indicated in parenthheses just behind SI units.

Example: 24.5 MPa (250 kgf/cm<sup>2</sup>, 3560 psi)

A table for conversion from SI units to other system units is shown below for reference purposees.

| Quantity | To Convert<br>From | Into            | Multiply By | Quantity    | To Convert<br>From | Into                | Multiply By |
|----------|--------------------|-----------------|-------------|-------------|--------------------|---------------------|-------------|
| Length   | mm                 | in              | 0.03937     | Pressure    | MPa                | kgf/cm <sup>2</sup> | 10.197      |
|          | mm                 | ft              | 0.003281    |             | MPa                | psi                 | 145.0       |
| Volume   | L                  | US gal          | 0.2642      | Power       | kW                 | PS                  | 1.360       |
|          | L                  | US qt           | 1.057       |             | kW                 | HP                  | 1.341       |
|          | m <sup>3</sup>     | yd <sup>3</sup> | 1.308       | Temperature | °C                 | °F                  | °C×1.8+32   |
| Weight   | kg                 | lb              | 2.205       | Velocity    | km/h               | mph                 | 0.6214      |
| Force    | N                  | kgf             | 0.10197     |             | min <sup>-1</sup>  | rpm                 | 1.0         |
|          | N                  | lbf             | 0.2248      | Flow rate   | L/min              | US gpm              | 0.2642      |
| Torque   | N⋅m                | kgf⋅m           | 1.0197      |             | mL/rev             | cc/rev              | 1.0         |
|          | N⋅m                | lbf∙ft          | 0.7375      |             |                    |                     |             |

## RECOGNIZE SAFETY INFORMATION

- These are the **SAFETY ALERT SYMBOLS**.
  - When you see these symbols on your machine or in this manual, be alert to the potential for personal injury.
  - Follow recommended precautions and safe operating practices.



SA-688

## **UNDERSTAND SIGNAL WORDS**

- On machine safety signs, signal words designating the degree or level of hazard - DANGER, WARNING, or CAUTION - are used with the safety alert symbol.
  - DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
  - WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
  - CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
  - DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs.
  - Some safety signs don't use any of the designated signal words above after the safety alert symbol are occasionally used on this machine.
- **CAUTION** also calls attention to safety messages in this manual.
- To avoid confusing machine protection with personal safety messages, a signal word IMPORTANT indicates a situation which, if not avoided, could result in damage to the machine.
- NOTE indicates an additional explanation for an element of information.



SA-1223

It's a preview. You can download the full file by clicking the link below.

## https://shopservicemanual.com/

Service Manuals from 2\$