# WORKSHOP MANUAL COMPACT TRACK LOADER

SVL75,SVL90

Kubota

## **CONTENTS**

TO THE READER TO THE READER	9. CONTROL VALVE3-I 10. TRAVEL MOTOR3-I		
INFORMATION	11. LIFT ARM CYLINDER		
CONTENTS	12. BUCKET CYLINDER	3-10180	
INFORMATION	13. HYDRAULIC QUICK HITCH	0.1404	
1. SAFETY FIRSTI-1	CYLINDER		
2. SAFETY PRECAUTIONS FOR WORK I-2	14. UNLOAD VALVE		
3. SAFETY DECALSI-7	15. AUX SOLENOID VALVE	3-M84	
4. MAIN SPECIFICATIONSI-12	16. QUICK HITCH SOLENOID VALVE		
5. DIMENSIONS I-14	(OPTION)	3-M85	
GENERAL	17. HIGH-FLOW SOLENOID VALVE		
CONTENTS	(SVL90 OPTION)	3-M87	
GENERAL	SERVICING		
1. MACHINE INDENTIFICATION	TROUBLESHOOTING		
2. ENGINE INDENTIFICATION	2. SERVICE DATA	3-S10	
3. GENERAL PRECAUTIONS	<ol><li>PERFORMANCE CHECKS AND</li></ol>		
4. HANDLING PRECAUTIONS FOR	ADJUSTMENT METHODS	3-S13	
ELECTRICAL PARTS AND WIRING	4. REMOVAL/INSTALLATION AND		
	DISASSEMBLY/ASSEMBLY	3-S25	
5. LUBRICANTS, FUEL AND COOLANTG-15	5. HYDRAULIC PIPING	3-S195	
6. TIGHTENING TORQUES	ELECTRICAL SYSTEM		
7. MAINTENANCE	CONTENTS		
8. SPECIAL TOOLSG-56	SERVICING		
ENGINE	DIAGNOSING MALFUNCTIONS	1 01	
CONTENTS	DIAGNOSING MALFUNCTIONS      WIRING CIRCUIT		
MECHANISM			
1. SVL 75 (V3307-DI-TE3-CTL) 1-M1	3. ELECTRONIC EQUIPMENT LAYOUT	4-55	
2. SVL 90 (V3800-DI-TE3-L6) 1-M21	4. UNPLUGGING ELECTRICAL		
SERVICING	CONNECTORS AND WIRING	4.07	
1. TROUBLESHOOTING1-S1	LAYOUT	4-57	
2. SERVICING SPECIFICATION1-S5	5. TERMINAL NAMES OF THE MAIN	4 0	
3. TIGHTENING TORQUES FOR	CONNECTOR	4-S57	
SPECIAL USE SCREWS, BOLTS	6. TROUBLESHOOTING (START-UP		
AND NUTS [SVL75]1-S15	EQUIPMENT VERSION)		
4. TIGHTENING TORQUES FOR	7. INSPECTIONS		
SPECIAL USE SCREWS, BOLTS	8. INSTRUMENT PANEL	4-S73	
AND NUTS [SVL90]1-S17	<ol><li>TROUBLESHOOTING</li></ol>		
5. CHECKING, DISASSEMBLING AND	(INSTRUMENT PANEL EDITION)		
SERVICING1-S19	10. BLOCK DIAGRAM OF METER	4-S161	
	CABIN		
MACHINE BODY	CONTENTS		
CONTENTS	MECHANISM		
SERVICING	AIR CONDITIONING SYSTEM	5-M1	
1. FRONT2-S1	2. WIPER		
2. UPPER STRUCTURE2-S9	SERVICING	0 10110	
3. TRACK FRAME2-S38	1. TROUBLESHOOTING	5-91	
HYDRAULIC SYSTEM	MAINTENANCE AND SERVICE		
CONTENTS	RELATED SPECIFICATIONS	E 0.1	
MECHANISM	3. TORQUE		
1. HYDRAULIC CIRCUIT 3-M1	TORQUE  4. PRECAUTIONS WHEN REPAIRING	5-35	
2. HYDRAULIC EQUIPMENT LAYOUT 3-M7		F 00	
3. HYDRAULIC SYSTEM	THE REFRIGERANT SYSTEM	5-56	
4. HST PUMP	5. INSPECTING AND CHARGING THE	- O4 1	
5. GEAR PUMP	REFRIGERANT SYSTEM		
6. GEAR PUMP (HIGH-FLOW	6. INSPECTION AND DISASSEMBLY		
	7. WINDOW WASHER	5-S67	
VERSION, SVL90 OPTION) 3-M61 7. TRAVEL CONTROL PILOT VALVE 3-M63	8. REMOVAL AND INSTALLATION OF		
	GLASS		
8. FRONT CONTROL PILOT VALVE 3-M68	9. LIGHTING EQUIPMENT	5-S78	

10. HYDRAULIC HOSE ROUTING ......5-S79

### TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the machine. It contains 4 parts: "Information", "General", "Mechanism" and "Servicing".

#### Information

This section contains information below.

- Safety First
- Safety Label
- · Specification
- Dimension

#### General

This section contains information below.

- Engine Identification
- · Model Identification
- General Precautions
- · Maintenance Check List
- · Check and Maintenance
- Special Tools

#### ■ Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870) for the diesel engine that this workshop manual does not include.

#### Servicing

This section contains information below.

- Troubleshooting
- · Servicing Specifications
- Tightening Torques
- · Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes several models, information or illustrations and photographs can show more than one model.

September, 2010

© KUBOTA Corporation 2010

### **Record of Revisions**

Last digit		
of the Code No.	Date	Main Revised Point and Corrective Measures
1	2011.02.11	Correction of the machine modification points. Correction of the wrong descriptions.
2		
3		
4		

It's a preview. You can download the full file by clicking the link below.

## https://shopservicemanual.com/

Service Manuals from 2\$